


PowerNow充電ステーション

PowerNow共享充电宝

PowerNow Sharing Power Bank Service

取扱説明書 使用说明书 Instruction Manual



POWER NOW
レンタルバッテリー

PowerNow 株式会社
www.pownow.jp

お問い合わせ窓口 0570-035566

アプリダウンロード

扫码下载app

Scan code to
download app



電話: 0570-035566

电话: 0570-035566

Tel: 0570-035566

メール: service@pownow.jp

邮箱: service@pownow.jp

Email: service@pownow.jp

PowerNow 充電ステーション

取扱説明書


JP

型番

NAS - 4

NAS - 8

NAS -16



目次

注意事項 4

各部名称 6

仕様 7

同梱物 9

POP貼り付け 12

お手入れ 13

バッテリーの補充と回収 14

ご使用前

設備について

点検・その他

設備保証証書 裏表紙

この度は当社の製品をお買い上げいただき、誠にありがとうございます。
ご使用になる前に、この取扱説明書をよくお読みになり正しくご使用ください。
この取扱説明書は、必ず保管してください。
設備保証証書に「購入日、設備QR番号、販売店名」を記入してください。

PowerNow 共享充电宝

使用说明书


ZHCN

型号

NAS - 4

NAS - 8

NAS -16



目录

注意事项 15

外观介绍 17

设备参数 18

设备清单 20

POP粘贴步骤 23

日常清洁 24

电池的补充与回收 25

使用前须知

关于设备

清理维护

设备保修书 附表


感谢您购买本产品。
在使用前，请认真阅读本说明书，正确使用。
阅读后，请将本说明书放在随时可以取用的地方并妥善保管。
请确认底面保修书【购买日、设备编号、销售店】等的填写。

PowerNow Sharing Power Bank Service

Instruction Manual

EN

Model
NAS - 4
NAS - 8
NAS -16



Catalogue		
Precautions	26	Before you use
Appearance	28	
Device parameters	29	About equipment
Component List	31	
Pop pasting step	34	
Daily cleaning	35	Cleaning and maintenance
Replenishment and recycling of power banks	36	
Device Warranty Attachment		

Thank you for purchasing our product.
Before using, please read this manual carefully and use it correctly.
After reading, please keep this manual in a safe place where it can be accessed at any time.
Please make sure to fill in the warranty at the bottom [Date of purchase, Device ID and Sales store], etc.

注意事項

正しく安全にお使いいただく為に、ご使用前に必ずこの取扱説明書にある指示事項を全てお読みください。表示内容を見逃して誤った使い方をした時に生じる危害や損害の程度を、次の表示マークで区分し、説明しています。

 警告	この表示の欄は、「死亡または重症を負う可能性が想定される」内容です。
 注意	この表示の欄は、「障害を負う危険性または物的損害のみが発生する可能性が想定される」内容です。

	この絵表示は、「禁止行為」の内容です。
	この絵表示は、「必ず実行」の内容です。

 警告 (WARNING)	
 分解・改造・修理の禁止 分解・改造・修理は絶対におやめください。けが・事故・破損・故障の原因になります。	 水に浸けたり、水などをかけたりしない 本体を水に浸けたり、水やコーヒー、ジュースなどの液体をかけないでください。液体が本体内部に流れ込むと、故障、漏電、火災の原因になります。水に浸けたり、大量の液体をかけてしまったときは使用を中止し、お買い上げの販売店にご相談ください。
 交流100V以外での使用やタコ足配線をしない タコ足配線などで定格を超えると発熱による火災の原因になります。	 異常・故障時は運転を停止して電源プラグを抜く 水漏れ、焦げ臭いなど異常や故障と思われるときは使用しないでください。火災・感電・けがの原因になります。
 本体に異物を入れない スロットに当社製バッテリー以外の異物を入れないでください。感電やけがの原因になります。	 お手入れするときは、電源プラグを抜く お手入れするときは、電源プラグをコンセントから抜いてください。感電の原因になります。
 幼児の手の届くところでは使わない 子供だけで使わせたり、幼児の手の届くところで使わないでください。けが、感電の原因になります。	 お手入れするときに塩素系、酸性タイプの洗剤は使わない 有毒ガスが発生し、健康を害する原因になります。

⚠ 警告 (WARNING)

- | | |
|--|--|
| <p>！ 電源プラグのお手入れをする
時々電源プラグを抜き、ほこりなどを除去してください。ほこりがたまると湿気などで絶縁不良となり、火災の原因になります。</p> | <p>⊘ 電源プラグは確実に差し込む
電源プラグはコンセントに根元まで確実に差し込み、傷んだプラグやゆるんだコンセントは使用しないでください。火災や感電の原因になります。</p> |
| <p>⊘ 濡れた手で電源プラグを抜きさししない
感電やけがの原因になります。</p> | <p>⊘ 電源コードを傷めない
電源コードを無理な力を加えたり、重いものをのせないでください。また、束ねたまま使用しないでください。火災や感電の原因になります。</p> |


⚠ 注意 (CAUTION)

- | | |
|--|---|
| <p>⌚ 長時間使用しないときは電源プラグを抜く
長時間使用しないときは、電源プラグをコンセントから抜いてください。けがややけど、絶縁劣化による感電や漏電火災の原因になります。</p> | <p>⊘ 不安定な場所に置いたり、傾けて使用しない
設備が正常に動作しない、または火災や感電の原因になります。</p> |
| <p>！ 電源プラグを抜くときは電源プラグを持って抜く
電源プラグを抜くときは、電源コードを持たずに、必ず先端の電源プラグを持って引き抜いてください。火災や感電の原因になります。</p> | <p>⊘ 本体の上に乗ったり、荷物を置いたりしない
本体の上に乗ったり、荷物をのせたりしないでください。故障やけがのおそれがあります。</p> |
| <p>！ 1分間通電後、バッテリーを入れる
設備を初回利用時、必ず1分間ほど通電してから、バッテリーをスロットに入れてください。通電せずに使用すると故障の原因になります。</p> | <p>！ グリーンランプが点灯するまで充電する
全てのバッテリーを差し込んだ後、スロット口付近のランプがグリーンになるまで充電してください。</p> |


各部名称

外観図


NAS-4




NAS-8



NAS-16



NAS - 4




仕様

認証 : PSE / CQC
 サイズ : 170mm x 142mm x 186mm
 スロット数 : 4
 重さ : 1.4kg

電気パラメータ

入力電圧 : DC5V
 静的入力消費電 : 2W
 最大入力消費電力 : 15W
 最大入力電流 : 3A
 電気消費量(24時間) : 0.048kWh
 適応環境温度 : 0℃~45℃

NAS -16




仕様

認証 : PSE / CQC
 サイズ : 260mm x 210mm x 409mm
 スロット数 : 16
 重さ : 6.9kg

電気パラメータ

入力電圧 : 100V ~240V
 静的入力消費電 : 6.5W
 最大入力消費電力 : 110W
 最大入力電流 : 0.8A~2.0A
 電気消費量(24時間) : 0.156kWh
 適応環境温度 : 0℃~45℃

NAS - 8



仕様

認証 : PSE / CQC
 サイズ : 260mm x 210mm x 295mm
 スロット数 : 8
 重さ : 4.6kg


電気パラメータ

入力電圧 : 100V ~240V
 静的入力消費電 : 3.5W
 最大入力消費電力 : 50W
 最大入力電流 : 0.6A~1.2A
 電気消費量(24時間) : 0.084kWh
 適応環境温度 : 0℃~45℃


NAS - 4




NAS-4 本体正面



NAS-4 本体上部




NAS-4 本体裏面



NAS-4 電源プラグ* 1



背面貼り付け用POP



バッテリー
2~3個



バッテリー挿入側




バッテリーLOGO側




利用Q&A ファイル


NAS - 8




NAS-8 本体正面



NAS-8 本体裏面




背面貼り付け用POP



バッテリー
4~6個



バッテリー挿入側




バッテリーLOGO側




利用Q&A ファイル

POPの取付方法(各設備共通)

NAS - 16




NAS-16 本体正面



NAS-16 本体背面



背面貼り付け用POP



バッテリー
8~12個



バッテリー挿入側




バッテリーLOGO側




利用Q&A ファイル

①




1. 両面テープをはがしてください。

②



2. POPの文字が隠れないよう、位置を注意しながら設備の後部に貼り付けてください。

③



3. しっかりくっつくよう、押し付けてください。

点検

設備のお手入れ

- 1.電源プラグを抜いてからお手入れしてください。本体背面のスイッチに洗剤をかけないでください。
- 2.濡れたタオルをよく絞ってから、本体を拭いてください。
- 3.お手入れして3 - 5分経ってから、電源を入れてください。
- 4.お手入れするときに塩素系、酸性タイプの洗剤は使わないでください。
- 5.異物が入れた場合、電源を落としてから、ピンセットなどを使って異物を取り出してください。

保証とアフターサービス

使用方法・お手入れのしかた・修理のご相談は購入した店舗にお問い合わせしてください。

設備はインターネットに接続障害が発生した場合、電源を切り、5分経ってから再起動してください。
接続障害が改善しない場合はPowerNowお問い合わせ窓口にご連絡をください。

PowerNowお問い合わせ窓

TEL:
0570-05566

メール:
service@powernow.jp

インターネットからのお問い合わせ



powernow


24時間受付・年末年始は休み

- 1、PowerNow株式会社(以下「弊社」)はお客様個人情報をお客様からのご相談への対応や修理及びその確認などに利用させていただき、これらの目的のためにご相談内容の記録を残すことがあります。
- 2、次の場合を除き、弊社以外の第三者に個人情報の提供・開示することはありません。
 - ①修理やその確認業務を委託する場合
 - ②法令の定める規定に基づく場合
- 3、個人情報に関するご相談は、お問い合わせいただきました窓口にご相談ください。

バッテリーの補充と回収

バッテリーの補充

- ◆ スロットにバッテリーが全部なくなりましたら、弊社よりバッテリーの補充を行います。
- ◆ バッテリーを弊社から郵送、または持ち込みでお客様にお渡します。
- ◆ バッテリーを受取後、速やかに空いたスロットに差し込んでください。設備は自動でバッテリーの登録が行われます。届いたバッテリーにロックがかかっており、スロットに差し込んで登録作業を行わないと、使用できないので、ご注意ください。



バッテリーの回収

- ◆ スロットがいっぱいになり、返却できなくなりましたら、弊社にご連絡をください。
- ◆ 弊社の担当より、遠隔でバッテリーを吐出し操作を行うので、吐き出したバッテリーを取り出してください。
お客様は吐き出したバッテリーを一時保管していただき、スロットにバッテリーが足りなくなりましたら、
- ◆ 保管したバッテリーを再度スロットに戻してください。
- ◆ バッテリーは3個以上貯まった場合、弊社より送付用封筒を送ります。
- ◆ 封筒にバッテリーを入れていただき、発送してください。



保証証書について



- ◆ 保証証書
必ず「購入日、QR番号、販売店名」が記入されていることをご確認ください。
保証証書の内容をお読みになり、大切に保管してください。
- ◆ 保証期間
購入日から1年間まで有効。

注意事项

为了防止给使用者及他人带来危害及财产损害，对遵守事项作如下说明。
由于错误使用方法而产生的危险及程度，按下列区分进行说明。

 警告	表示无视该标志而错误使用时，可能会导致人死亡、重伤或引发火灾的内容。
 注意	表示无视该标志而错误使用时，可能会导致人轻伤或造成物质损失的内容。

	该标识表示禁止的行为。
	该标识表示必须执行的【指示】。


 警告 (WANRNING)	
 禁止拆卸修理及改造 发生故障、损坏时，请勿使用。 此外，请不要自行拆卸、修理、改造。 否则会导致触电或引起故障。	 请勿浸入水中或喷洒水等 不要将主机浸入水中或向主机喷洒洒水、咖啡、果汁等液体。 水等液体流入主机内部会引发故障、漏电、火灾。 浸入水中或喷洒水等液体时，请停止使用，并咨询销售店。
 请勿在100V交流电以外时使用或使用多头插座 使用多头插座等而超过额定值时，会由于发热而引发火灾。	 异常或故障时停止使用并拔下插头 有烧焦气味等异常或故障发生时，请勿使用。 否则会导致火灾、触电、受伤。
 请勿把异物放入主机 否则会出现短路或设备故障，引起安全隐患。	 维护时拔下电源插头 维护时，请将电源插头从插座拔出。 否则会导致触电。
 请勿放置在儿童可触碰区域 请不要让儿童单独使用，或在幼儿可接触到的地方使用。 否则会导致烧伤、受伤、触电。	 维护时，请勿使用含氯、酸性洗涤剂 否则会产生有毒气体，损害健康。

 警告 (WANRNING)	
 电源插头的维护 请偶尔拔下电源插头进行除尘等。 若灰尘堆积，会由于湿气等造成绝缘不良而引发火灾。	 确保插好电源插头 将电源插头插入插孔底部。请勿使用破损的电源插头或松动的插座。 否则会导致火灾、触电。
 请勿用湿手插拔电源插头 否则会导致触电、受伤。	 不损坏电源线 不要用力拉扯电源线，或在电源线上放置重物。此外，请不要捆扎着使用。 否则会导致火灾、触电。


 注意 (CAUTION)	
 长时间不使用时拔下电源插头 长时间不使用时，请拔下电源插头。 否则会导致烧伤、受伤，或由于绝缘劣化而引起的漏电、触电、火灾。	 不放置在不平稳的地方或倾斜着使用 以免导致设备故障，产生不必要的经济损失。
 拔下电源插头时,务必手持插头 拔下电源插头时,请勿手持电源线，务必手持前端的插头。 否则会导致火灾、触电。	 请勿骑坐、倚靠设备 请不要骑坐或倚靠在设备上。 否则会导致故障或受伤。
 通电1分钟后再放入电池 初次使用设备，务必通电1分钟后再把电池放入仓道。 否则会引起故障。	 请充电至绿色指示灯亮 所有电池插入设备后，需要进行充电，直至绿色指示灯亮起。

外观图


NAS-4



NAS-8



NAS-16




NAS - 4

产品配置

认证	: PSE / CQC
尺寸 (长*宽*高)	: 170mm x 142mm x 186mm
充电仓	: 4
重量	: 1.4kg

电气参数

输入电压	: DC5V
静态输入功耗	: 2W
最大输入功耗	: 15W
最大输入电流	: 3A
静态用电量 (24小时)	: 0.048kWh
环境温度	: 0℃~45℃




NAS - 8

产品配置

认证	: PSE / CQC
尺寸 (长*宽*高)	: 260mm x 210mm x 295mm
充电仓	: 8
重量	: 4.6kg

电气参数

输入电压	: 100V ~240V
静态输入功耗	: 3.5W
最大输入功耗	: 50W
最大输入电流	: 0.6A~1.2A
静态用电量 (24小时)	: 0.084kWh
环境温度	: 0℃~45℃




NAS - 16

产品配置


认证	: PSE / CQC
尺寸 (长*宽*高)	: 260mm x 210mm x 409mm
充电仓	: 16
重量	: 6.9kg

电气参数


输入电压	: 100V ~240V
静态输入功耗	: 6.5W
最大输入功耗	: 110W
最大输入电流	: 0.8A~2.0A
静态用电量 (24小时)	: 0.156kWh
环境温度	: 0°C~45°C




NAS - 4




NAS-4 正面




NAS-4 上部




NAS-4 背面



NAS-4 电源线*1



设备背面 POP



充电宝 *2~3个



充电宝插入侧




充电宝标志侧




店铺用 QA


NAS - 8




NAS-8 正面



NAS-8 背面



设备背面 POP



充电宝 *4~6个



充电宝插入侧




充电宝标志侧




店铺用 QA


NAS - 16




NAS-16 本体 正面



NAS-16 本体背面



设备背面 POP



充电宝 *8~12个



充电宝插入侧



充电宝标志侧



店铺用 QA

POP粘贴步骤（各设备通用）



日常清洁

清洁设备外观的灰尘污垢

- 1.要断电清洁，不能清洁电源开关位置。
- 2.要使用拧干的湿毛巾，不能有滴水情况。
- 3.清洁完成需要静置3-5分钟，再开机。
- 4.不能使用带有腐蚀性液体清洁。
- 5.如仓道中被塞入异物，请在断电后用镊子等工具将异物小心取出。

保修及售后服务

使用方法、维护方法及修理等，如需详细了解，请咨询销售店。
设备出现网络连接异常，可关机后五分钟重新开机。
如设备仍然无法连接互联网，请拨打客服电话或联系PowerNow营业人员。

PowerNow咨询窗口

咨询电话：
0570-05566

邮件：
service@powernow.jp

访问官方网站

www.powernow.jp

24小时受理（除年末年初）

1.PowerNow株式会社（以下称“我司”）将客户的个人信息用于客户的咨询服务及维修服务等，为此会留下协商内容。

2.除以下情况外，不会向我司以外的第三方提供或公开个人信息。

- ① 委托维修或确认业务时
- ② 基于法律规定的情况


3.关于个人信息的咨询，请联系PowerNow咨询窗口。

电池的补充与回收

电池的补充

- ◆ 当仓道内电池被借完时，由我司进行电池的补充。
- ◆ 我司会上门服务或为您邮寄电池。
- ◆ 收到电池后，请及时放入空仓中。设备会自动进行电池的登录。补充的电池是上锁状态，如若不放入仓道进行登录，将无法使用。


NAS-4



* 1

NAS-4 配备不少于1枚电池


NAS-8



* 2

NAS-8 配备不少于2枚电池

NAS-16



* 4

NAS-16 配备不少于4枚电池

电池的回收

- ◆ 当设备内电池塞满影响用户归还时，请与PowerNow营业人员联系。
- ◆ PowerNow将远程操作，弹出电池，届时请店家取出电池代为保管。
- ◆ 如后续需要补充电池，可将保管中的电池插回设备中。
- ◆ 如您保管的电池超过3个，PowerNow将给您邮寄回收信封，请将电池放入信封后邮寄给我们。



保修书



- ◆ 保修书
请务必确认保修书上【购买日期、设备编号、销售店名】填写清楚后再从PowerNow营业人员处收取本保修书。
认真阅读保修书内容后，请妥善保管。
- ◆ 保修期
保修期为购买日起1年。

Precautions

In order to prevent harm to users or other person and damage to property, the compliance matters are explained below.
The dangers and levels due to incorrect operation are explained below.

 Caveat	It may cause death, serious injury, or fire if used incorrectly or ignoring this mark.
 Note	It may cause minor injury or material damage if used incorrectly or ignoring this mark.

	This sign indicates prohibited actions.
	This mark indicates the [instructions] that must be performed.

 **WARNING**



Prohibition of disassemble, repair and modification
Do not use it if it is broken or damaged. Please do not disassemble, repair, or modify by yourself, otherwise it may cause electric shock or cause failure.



Do not immerse in water or spray water, etc.
Do not immerse the device in water or spray water, coffee, juice and other liquids on the device. Liquids such as water flowing into the device will cause malfunctions, electricity leakage, and fire. Please stop using when immersed in water or sprayed with water, etc. and consult a sales store.



Do not use a multi-outlet or other than 100v AC
Use of multiple sockets, exceeding the rated value etc., may cause fire due to heat generation.



Stop using and unplug when abnormal or malfunctioning
Do not use if there is an abnormality such as burnt odor or malfunction, otherwise it may cause fire, electric shock and injury.



Do not put other objects in the host
Otherwise, short circuit or equipment failure may occur and it will cause potential safety hazards.




Unplug the power plug during maintenance
During maintenance, please unplug the power plug from the socket. Otherwise it may cause electric shock.



Keep out of reach of children
Please do not let children use it alone, or use it out of reach of young children. Otherwise it may cause burns, injury, or electric shock.



During maintenance, please do not use chlorine or acid detergent
Otherwise, toxic gases will be generated and damage to health.




! WARNING	
! Maintenance of power plug Unplug the power plug occasionally for dust removal etc. If dust accumulates, it may cause insulation and fire due to moisture defective.	⊘ Make sure the power plug is plugged in Insert the power plug into the bottom of the jack. Do not use a damaged power plug or a loose socket. Otherwise it may cause fire or electric shock.
⊘ Do not plug or unplug the power plug with wet hands Otherwise, it may cause electric shock and injury.	⊘ Do not damage the power cable Do not pull the power cable forcibly, or place heavy objects on the power cable. Also, do not use it in a bundle. Otherwise, it may cause fire or electric shock.

! CAUTION	
⚡ Unplug the power cable when not in use for long time When not in use for a long time, please unplug the power plug. Otherwise, it may cause burns, injuries, or leakage, electric shock, or fire due to insulation deterioration.	⊘ Not placed in an unstable place or Use at an angle Don't place it in an unstable place or at an angle when you use it. Otherwise, it may cause equipment failure and unnecessary economic losses.
! When unplugging the power plug, be sure to hold the plug When you unplug the power plug, do not hold the power cord, be sure to hold the plug on the front end. Otherwise it may cause fire or electric shock.	⊘ Do not ride or lean on equipment Please do not ride or lean on the device, otherwise it may cause malfunction or injury.
! Insert the battery after 1 minute of power When using the device for the first time, please be sure to power it on for 1 minute before putting the battery into the slot. Otherwise, it may cause a malfunction.	! Please charge power banks until the green indicator light is on After all power banks are inserted into the device, they need to be charged until the green indicator light is on.


Appearance




NAS-4



NAS-8




NAS-16



Device parameters

NAS – 4




Configuration

Certificate	: PSE / CQC
Size (L*W*H)	: 170mm x 142mm x 186mm
Charging bin	: 4
Weight	: 1.4kg

Electrical parameters

Input voltage	: DC5V
Static input power consumption	: 2W
Maximum input consumption	: 15W
Maximum input current	: 3A
Static Electricity	: 0.048kWh
Working temperature	: 0°C~45°C

NAS – 8




Configuration

Certificate	: PSE / CQC
Size (L*W*H)	: 260mm x 210mm x 295mm
Charging bin	: 8
Weight	: 4.6kg

Electrical parameters

Input voltage	: 100V ~240V
Static input power consumption	: 3.5W
Maximum input consumption	: 50W
Maximum input current	: 0.6A~1.2A
Static Electricity	: 0.084kWh
Working temperature	: 0°C~45°C

NAS – 16



Configuration

Certificate	: PSE / CQC
Size (L*W*H)	: 260mm x 210mm x 409mm
Charging bin	: 16
Weight	: 6.9kg

Electrical parameters


Input voltage	: 100V ~240V
Static input power consumption	: 6.5W
Maximum input consumption	: 110W
Maximum input current	: 0.8A~2.0A
Static Electricity	: 0.156kWh
Working temperature	: 0°C~45°C

Component List


NAS - 4




NAS-4 Front




NAS-4 Upper




NAS-4 Back



Nas-4 power cord * 1



Pop on the back of device



Power bank * 2 ~ 3pcs



Power bank insert side




Power bank logo side




Shop QA


NAS - 8




NAS-8 Front



NAS-8 Back



Pop on the back of device



Power bank * 4 ~ 6pcs



Power bank insert side




Power bank logo side




Shop QA


NAS - 16




NAS-16 Front



NAS-16 Back



Pop on the back of device



Power bank * 8 ~ 12pcs



Power bank insert side




Power bank logo side



Shop QA


Pop pasting step (It is the same for every model.)

①




1. Tear the sticker tape off.

②



2. The dotted line on the POP shall be aligned with the upper part of the equipment for pasting.

③



3. Paste and press the pop.

Daily cleaning

Clean dust and dirt from the appearance of the device

- 1. Before cleaning, please turn off of the device. Do not clean the power switch.
- 2. Use a wet towel that has been wrung out, and there must be no dripping.
- 3. Make it wait for 3–5 minutes and turn it on after cleaning.
- 4. Do not use corrosive liquids for cleaning.
- 5. If the slot has filled with litters , please remove the litters carefully with tweezers or other tools after turn the device off.

Warranty and after-sales service

For more information of usage method of the device , maintenance method and repair, etc. , please consult PowerNow sales staff.

It can be restarted for five minutes after shutting down when the device has an abnormal network connection.

If the device still cannot connect to the internet, please call customer service or contact a PowerNow sales staff.

Customer Consultation

Consultation:
Tel: 0570-05566

Email:
service@powernow.jp

Visit our website



www.powernow.jp




24-hour service (except at the beginning or end of the year)

- 1. PowerNow Co., Ltd (hereinafter referred to as "our company") will use the customer's personal information for the customer's consulting services and maintenance services, etc., for which the negotiation content will be kept.
- 2. Our company will not provide or disclose personal information to any third party except the following circumstances.
 - ① Authorize maintenance or confirm business
 - ② Based on the situation of legal provisions
- 3. For personal information, please contact PowerNow.

Replenishment and recycling of power banks

Power Bank replenishment

- ◆ When all power banks are rent, we will replenish power banks.
- ◆ We will come to your shop or mail the power banks for you.
- ◆ After receiving the power banks, please put it into the empty slot in time. The device will automatically record. The replenishment power banks are locked. If you do not put it in the device for registration, you will not be able to use it.

NAS-4	NAS-8	NAS-16
 NAS-4 is equipped at least with 1 power bank	 NAS-8 is equipped at least with 2 power banks	 NAS-16 is equipped at least with 4 power banks

Powerbank recycling

- ◆ When the device is full with power banks and it affects other users to return, please contact the Power-Now staff.
- ◆ PowerNow will remotely eject the power bank. Please keep the power banks safe.
- ◆ If you need to replenish the power bank, you can insert the safekeeping battery into the device.
- ◆ If you are keeping more than 3 power banks, PowerNow will mail you a recycling envelope. Please put the power banks in the envelope and mail it to us



Warranty



◆ Warranty

Please make sure that the warranty is written by [Date of purchase, Device ID and Sales store] before receiving it from PowerNow sales staff.

Please keep it in a safe place after reading the contents of the warranty carefully .

- ◆ The warranty period is 1 year from the purchasing date.